



# REVOSPIN

## User Manual





**LED Flames**





## How to Set Up

1





Step 1: Unravel the red fabric and insert the aluminum plate in the middle slot.

2



Step 2: Plug-in the supplied power cable to the LED Flame and power on.

3



Step 3: Using the remote, push the unlock button to turn on the LED Flames.

4

